

Thank you for purchasing our equipment. Please read this manual carefully and heed the safety warnings and instructions before installing, using or repairing the equipment. This will ensure not only the protection of persons, but also the long life of the equipment.


## TECHNICAL PARAMETERS

Power input	220-240 V / 50 Hz
Power	2000W
Modes	fan for air circulation, low heating, high heating
Adjustable thermostat	18°C, 21°C, 24°C, 27°C
Timer	Up to 12 hours
Weight	1,75kg

## SAFETY NOTICE


- Do not disassemble, modify or adjust the equipment.
- The device has hot surfaces during use and for some time after switching off, take extra care.
- Leave a minimum of 1m clearance around the device on each side.
- Do not leave the device unattended.
- The equipment must not be used by anyone who does not understand the risks associated with improper use of the equipment.
- Do not use the device or any part of it (including the cable) if it is damaged.
- Do not cover the power cord with carpet or anything similar. Do not place the device directly under the socket.
- Do not block the air inlet or outlet.
- The device has hot (sparking) parts inside. Therefore, do not use the device in areas where gasoline, paint, explosive and/or flammable liquids are used or stored.
- Always plug the device directly into a power outlet. Never use with an extension cord or anything similar.
- To disconnect the device, turn the controls to OFF, then pull the plug from the socket. Pull the plug firmly, DO NOT disconnect the plug by pulling the cable!
- Unplug the power cord whenever the device is not in use.
- The device is intended for household use only. Never use it outdoors.
- Always use the device on a dry and level surface. Use only on the floor.
- Do not use this device with a programmer, timer, or other device that automatically turns on the heater.
- Do not use this device in the immediate vicinity of a bath, shower or swimming pool.
- At the end of its useful life, the equipment must be disposed of in a designated place. The equipment does not belong in normal household waste.
- Do not place anything on the device or cover it with anything.
- If there are children around the facility, they must be supervised at all times.
- This device is not equipped with a room temperature control device. Do not use this heater in small rooms if they are occupied by persons who are unable to leave the room on their own, unless constant supervision is provided.

## DESCRIPTION OF EQUIPMENT



## INSTALLATION



1. Remove the base and the stand from the box
2. Connect the bottom cover (Figure 1)  
Unscrew the thread (Figure2)  
Replace the base and screw it on (Figure 3)
3. Plug the power cord into a power outlet
4. To turn on, toggle the switch (I/O) on the back of the device



## CONTROL


1. To switch on, press the  button. To switch off, press the button again. The device will cool down and switch off after a few seconds.
2. When the device is in operating mode, pressing  button repeatedly will change the device's operating status: low temperature-high temperature-18°C-21°C-24°C-27°C-cold air.
3. When the device is in the working state, press the  button to turn on the timer. Each press of this button will extend the timer by 1 hour (up to 12h). The operation of the device will automatically stop, depending on the number of hours set.
4. When the device is in working condition, press the  button to start the rotation.

## DESCRIPTION OF DISPLAY AND BUTTONS



## REMOTE CONTROL

1. After opening the remote control bag, remove the battery cover and insert 2 AAA batteries for direct use.
2. When using the remote control, the transmitter on the front of the remote control must be aligned with the receiving window on the product.
3. The remote control can normally be used at a distance of approximately 4 metres from the front of the product and within a range of 30 degrees.
4. If you do not use the device for a long time, remove the battery.



## MAINTENANCE

- Before cleaning, turn off the power and disconnect the plug from the mains.
- After the product has cooled completely, wipe the outer surface with a soft cloth and clean the air vents with a soft brush.
- After cleaning, until the product is completely dry, it can be used with electricity or placed in its original packaging and placed in a dry and ventilated place for proper storage.
- Do not rinse with water during cleaning and prevent water from entering the device.

The product has been issued with a CE declaration of conformity in accordance with the applicable regulations.  
On request from the manufacturer: [info@solight.cz](mailto:info@solight.cz), or downloadable from [www.solight.cz/en](http://www.solight.cz/en).



**SOLIGHT**

Solight Holding, s.r.o., Na Brně 1972, Hradec Králové 500 06, Czech Republic.