

Thank you for purchasing our product. Before using or repairing the device, please read this manual carefully and pay attention to the safety warnings and instructions. This will ensure not only personal safety but also the long-term durability of the device.

CHARGING

- The USB charging port is located under the rubber seal on the side of the device.
Charging time: 5 hours
Battery life min/max: 2 hours/4 hours
- The red indicator light flashes during charging; once the device is fully charged, it remains lit continuously.

LIGHTING MODES

- Switch between lighting modes by repeatedly pressing the button .
6 lighting modes: centre light 100%/50%, side lights 100%/50%, all lights 100%, flashing

WARNING

- Do not attempt to charge the light in a damp or wet environment.
- Do not dismantle or repair the device, and do not expose it to extreme temperatures or open flames.
- Once fully charged, do not leave the light connected to the mains for long periods, as overcharging may reduce the battery's lifespan.
- Store the light in a cool, dry place away from direct sunlight or extreme temperatures.

The light source in this lamp is non-replaceable; at the end of its service life, the entire lamp must be replaced and disposed of at a designated collection point. This product contains a light source which, for design reasons, cannot be removed for verification, and therefore the entire product is considered to be the light source. The power cable cannot be replaced; if it is damaged, the device must not be used any further.

A CE Declaration of Conformity has been issued for the product in accordance with applicable regulations.
Available on request from the manufacturer: info@solight.cz, or for download at www.solight.cz/en.

