


Thank you for purchasing our product. Before installing, using or repairing the product, please read this manual carefully and pay attention to the safety warnings and instructions. This will ensure not only personal safety but also the long-term durability of the product.

INSTALLATION

1. Switch off the power supply before installation
 2. Drill holes in the mounting surface and insert wall plugs
 3. Secure the mounting brackets to the surface using screws
 4. Remove the top cover of the luminaire
 5. Fit the luminaire into the bracket
 6. Feed the power cable into the luminaire body through the cable gland and connect the cable to the terminal block
 7. Secure the top cover of the luminaire
 8. Secure the luminaire with clips
- Use the switch to select the light temperature (3000 K, 4000 K or 6500 K).
 - The devices can be connected to each other using connectors

WARNING

- Prevent improper handling of this appliance and always follow the guidelines for using electrical appliances.
- Do not hang anything on the light fitting or cover it with anything.
- Keep the user manual in a safe place.
- Installation must only be carried out by a qualified technician
- Operating temperature: -20°C to 50°C.



The light source in this luminaire is non-replaceable; at the end of its service life, the entire luminaire must be replaced and disposed of at a designated collection point. This product contains a light source which, for design reasons, cannot be removed for inspection; therefore, the entire product is considered to be the light source. The power cable cannot be replaced; if it is damaged, the device must not be used any further.

A CE Declaration of Conformity has been issued for the product in accordance with applicable regulations. Available on request from the manufacturer: info@solight.cz, or for download at www.solight.cz/en.

