EN WD1002-W | WD1002-B
Track lighting

Thank you for purchasing our product. Before installing, using or repairing the product, please read this manual carefully and pay attention to the safety warnings and instructions. This will ensure not only personal safety but also the long-term durability of the product.

INSTALLATION

Switch off the power supply before installation!

1. Connect and secure the two rails using an I- or L-type connector.
2. Connect the supply cable to the terminal block and then secure the rails to the ceiling using screws.
3. Press the locking levers and insert the fixture into the bracket. Turn the light source into the fixture to install it.
4. Flip the locking lever to secure the luminaire to the track. Once securely fixed, switch on the power supply.

Type I



Type L



WARNING

- Installation must only be carried out by a qualified electrician.
- Power supply: 220–240 V AC 50/60 Hz.
- For indoor use only.
- Do not dismantle or repair the device.
- There are no replaceable parts in the device.

The light source in this luminaire is non-replaceable; at the end of its service life, the entire luminaire must be replaced and disposed of at a designated collection point. This product contains a light source which, for design reasons, cannot be removed for verification, and therefore the entire product is considered to be the light source.

A CE Declaration of Conformity has been issued for the product in accordance with applicable regulations.
Available on request from the manufacturer: info@solight.cz, or for download at www.solight.cz/en.

Solight Holding, s.r.o., Na Brně 1972, Hradec Králové 500 06, Czech Republic.